




Function Introduction



Pair with RF receiver (Method 2)



- Step 1:**
Do wiring the RF receiver according to wiring diagram (please refer to the instruction of RF receiver that you would like to pair with).
- Step 2:**
Click ON/OFF button to activate the remote
- Step 3:**
Power of and power on the receiver
- Step 4:**
Choose and click a zone number (zone 4) e.g. 1 twice, then press and hold it continuously and quickly within 10 seconds, LED lights connected with the RF receiver flicker once means the receiver is paired with zone 4 successfully

CCT RF touch dimmer control for led lighting up to 4 zones - SUNRICHER - Perfect RF

Ref. SR-2819S-CCT

Barvni temperaturni regulator za LED diode SR-2819S-CCT je daljinski upravljalnik, ki omogoča hitre in natančne prilagoditve barvne temperature ter neodvisno regulacijo svetlosti za vsako belo barvo. Zasnovan z dotikovalnim barvnim kolesom, barvni temperaturni regulator lahko prilagodi barvno temperaturo za naravno belo, toplo belo in hladno belo LED.


Pair with RF receiver (Method 1)



- Step 1:**
Do wiring the RF receiver according to wiring diagram (please refer to the instruction of RF receiver that you would like to pair with).
- Step 2:**
Click ON/OFF button to activate the remote
- Step 3:**
Click the "Learning Key" button on RF receiver or re-power on the receiver three times continuously to set it into pairing status.
- Step 4:**
Choose and click a zone number (zone 4) e.g.
- Step 5:**
Touch the color wheel, LED lights connected with the RF receiver flicker once means the receiver is paired with zone 4 successfully

Product data

Potrdila	CE, ROHS
Razred energetske učinkovitosti	A+ (2021)
Barvna kontrola	CCT
Dimenzije (mm) LxIxh	120X55X17mm
Garancija	Po zakonski garanciji: 3 leta
IP	IP20
Material	Plastika
Obseg zaznavanja (m)	25000
Senor	Ne
Nomin Spannung (V)	4,5V/DC
Zunanja raba	Ne
Življenjska doba (h)	35000



Product variants

Reference

Attributes

SR-2819S-CCT

